

97W TUNABLE CIRCULAR HIGH BAY

Installation Guide

∕!∖ WARNING


PLEASE READ ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION

- To prevent personal injury or product damage only licensed electricians should install.
- To avoid electric shock or component damage disconnect power before attempting installation or servicing.
- This product must be installed in accordance with the national electric code (NEC) and all applicable federal, state and local electric codes and safety standards. - Disconnect product and allow cooling prior to servicing.
- Any alteration or modification of this product is expressly forbidden as it may cause serious personal injury, death, property damage and/or product malfunction.
- To prevent product malfunction and/or electrical shock this product must be properly grounded.
- This luminaire is designed to operate in ambient temperatures ranging from -40°F to 113°F (-40°C to 45°C) and to be horizontally mounted with the LEDs facing down. This product must be installed in accordance with the applicable installation code by a Person familiar with the construction and operation of the product and
- the hazards involved.
- MIN 167°F (75°C) SUPPLY CONDUCTORS
- This product is not suitable for several special environments, such as places with corrosive gas liquids or high pressure water vapor.

Installation Guide


Hook Installation

- 1. Thread the power cord through the hole in the center of the hook and tightly screw the hook into the 3/4" hole on the top of the fixture.
- 2. Tighten the M4x8 screw to secure the hook.
- 3. Make electrical connections according to the wiring diagram.



Pendant Mounting With 3/4" Conduit

- 1. Make electrical connections according to the wire diagram.
- 2. Thread the fixture onto the 3/4" NPT conduit and secure using the M4x8 screw.



3/4" Conduit (Not Included) Note: Conduit must be made of steel with a thickness greater than 2.5mm, and with a minimum load-bearing greater than 25lb. for the conduit thread head.


Power & CCT Adjustment Controls

Adjust the dial switch to the desired power level and color temperature to match the application requirements, as demonstrated below:

CCT Toggle Switch Power Toggle Switch LV4 40% LV3 60% 4KK 4000K LV2 80% 5KK 5000K LV1 100%

NOTE: The Power & CCT Adjustment dials are located under a white rubber cover that prevents water and dust ingress. Do not remove the covers.

WIRING DIAGRAM



Note: 2 dimming wires are in the driver box.

Adjustable Surface Mounting Bracket

- 1. Thread the power cord through the hole in the center of the hook and tightly screw the hook into the 3/4" hole on the top of the fixture.
- 2. Tighten the M4x8 screw to secure the hook.
- 3. Secure the mounting bracket to the surface, adjust to the desired angle, and lock the angle adjustment screw.
- 4. Make electrical connections according to the wiring diagram.

