LED AREA LIGHT


PLEASE READ ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION

- To prevent personal injury or product damage only licensed electricians should install.
- To avoid electric shock or component damage disconnect power before attempting installation or servicing.
- This product must be installed in accordance with the national electric code (NEC) and all applicable federal, state and local electric codes and safety standards.
- Disconnect product and allow cooling prior to servicing.
- Any alteration or modification of this product is expressly forbidden as it may cause serious personal injury, death, property damage and/or product malfunction.
 To prevent product malfunction and/or electrical shock this product must be properly grounded.
- This luminaire is designed to operate in ambient temperatures ranging from -40°C to 45°C and to be horizontally mounted with the LEDs facing down.
- This formation is designed to operate in ambient temperatures ranging from 40 0 to 40 0 and to be noticinally monitor with the LED's lating down.
 This product must be installed in accordance with the applicable installation code by a Person familiar with the construction and operation of the product and the hazards involved.
- MIN 75°C SUPPLY CONDUCTORS
- CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR
- CAUTION RISK OF FIRE
- Slipfitter Mounted with PHOTOCELL function elevation angle should not exceed 15 degrees

Installation Guide


Square/Round Pole

- 1. Remove the side plate from mounting bracket. Please skip to step 3 if mounted onto the square Pole.
- 2. Attach round pole mounting plate on mounting bracket.
- 3. Route the cord into mounting bracket through the hole for wiring, slide the fixture onto the bracket and tighten 2 bottom screws.
- 4. Slightly drag the wires to make sure the hole on bracket is sealed by silicon gasket.
- 5. Make wiring connection as per wire diagram below, replace the side plate and fasten screws.






- 1. Connect the wires to L / N / GND
- 2. Remove the cover and adjust the bracket to the desired angle
- 3. Install the bracket on the pole and fix it with screws





Wall Mount

- 1. Remove the side plate by loosen the screws.
- 2. Fix the back plate onto the arm bracket with screws provided.
- 3. Use the metal template provided to locate footprint on the wall to drill the holes, then fix the bracket on the wall with screws.
- Route the power cord into wall mount bracket, slide the fixture onto the mounting bracket, then tighten bottom screws.
- 5. Make wiring connection inside of bracket and replace the



side plate with screws.





ACCESSORY LIST

Mounting Type	Accessory	Specifications	Quantity
Slipfitter mount	Slipfitter	Adjustable slipfitter	1
1 O 2 O Square mount	① Pole Mount Arm	19.9 x 17.7 x 9cm Square pole mount arm	1
	② Bolt	# 1/2'' x 1.97'' Stainless Steel Hexagon Hexagon head bolt	2
1 2 Round mount	① Pole Mount Arm	19.9 x 17.7 x 9cm Square pole mount arm	1
	② Bolt	# 1/2" x 1.97" Stainless Steel Hexagon Hexagon head bolt	2
	③ Adaptor	17.7 x 8.8 x 1.3cm Round pole adaptor	1
1 2 3 4 0 0 0 0 0 0 0 0 0 0 0 0 0	① Pole Mount Arm	19.9 x 17.7 x 9cm Square pole mount arm	1
	② Wall Mount Plate	20.3 x 15.2 x 0.5cm Steel Plate	1
	③ Wall Mount Template	18.8 x 14.4 x 0.05cm Back Plate	1
	④ EVA Gasket	L119W119H3,40°EVA Gasket	1
	⑤ Bolt	KM4 x 10'' Stainless Steel flat head bolt	4
	© Bolt	# 1/2" x 1.46" Stainless Steel Hexagon head bolt	2
Others	Twist-lock photocell	120-277V 3-Pin	1
	Receptacle	3-Pin receptacle	1
	Bolt	PM4 x 8 Stainless Steel, Round Flat bottom Bolt	2
	Occupancy Sensor	120-277V 0-10V Bi-level	1